

## Draper Header bracket instructions



Fig. 1






Fig. 2



Head fastens to hauler bracket by inserting pin through sleeve on leg bottom. (Fig. 3) Riser brackets can be positioned on center of lower rail if needed to support the combine adapter.

(Fig. 4)



Fig. 3

Fig. 4